

# SNES TO GENESIS-MEGADRIVE ADAPTER

Document rev.1 for adapter ADAP-SNES2MD


## button mappings

The following mappings were developed to accomodate a variety of games, based on their specific button assignments.

These mappings are enabled by holding the activation button combinations on the SNES controller when connecting the adapter or turning the console on.

GENESIS	SNES 1	SNES 2	SNES 3	SNES 4	SNES 5
Mode	Select	Select	Select	Select	Select
A	A	B	Y	X	A
B	B	A	B	Y	B
C	X	Y	A	B	X
X	Y	X	L	A	Y
Y	L	L	X	R	L
Z	R	R	R	L	R
D-Up	D-Up	D-Up	D-Up	D-Up	D-Down
D-Down	D-Down	D-Down	D-Down	D-Down	D-Up
D-Left	D-Left	D-Left	D-Left	D-Left	D-Right
D-Right	D-Right	D-Right	D-Right	D-Right	D-Left

MAPPINGS	ACTIVATION
SNES 1	Default
SNES 2	Hold B
SNES 3	Hold Y
SNES 4	Hold X
SNES 5	Hold L



Copyright (C) 2013 raphnet technologies inc.

Genesis and Super Nintendo are registered trademarks of Sega and Nintendo. We are not affiliated with them.

Art and design by Sion: [www.sionart.com](http://www.sionart.com)